

Access Rights


How to add user profiles

You must set up a user profile that is the same as in the Transmitter's Access Rights Setup. If you do not have a user profile, you may connect using the Guest account. Note that the 'G' in Guest is uppercase. Usernames and Passwords are case-sensitive. There is no password for the Guest profile. When the software runs, you must log in before the interface will activate, unless Admin is the only profile set up. The Admin profile has full rights.

1. Double-click the Users icon.



2. Click the **Add** button.



3. Enter the Username and Password. The other fields are optional. The Username and Passwords must be the same as those set up in the Transmitter's Remote Sites set up. Click **Save**. Click **Close**.

